

Connecting Your CM100 Condenser Microphone with an Audio Interface

Step 1

Connect your microphone to the input of Audio Interface using the XLR cable included in the box (Refer the diagram below)



Step 2

Switch ON the 48V Phantom Power Supply.



Connecting Your CM100 Condenser Microphone with an Audio Interface using External 48V Phantom Power Supply

Note : Please use this option only if your Audio Interface **DOES NOT** have an in-built 48V Power Supply.

Step 1

Connect your microphone to the input of Phantom Power Supply using the XLR cable included in the box (Refer the diagram below)



Step 2

Connect output of power supply to the input of Audio Interface.

